

WIRING INSTRUCTIONS FOR CURRENT CARRYING

HAYDEN

SUPERVALVE

U. S. PAT. 4,758,170
CAN. PAT. 1 267 174


NEW CONSTRUCTION

1. Install BUILDING WIRE CONDUCTORS (1) through the approved type electrical CONNECTOR (2) (supplied) until they protrude approximately six inches from connector. Seat connector firmly into the opening atop the WIRING COMPARTMENT (4). Insert and secure LOCKING TAB (3).
2. Splice wires from INLET VALVE RECEPTACLE (7) to the protruding building wire conductors with #31 TWIST-ON WIRE CONNECTORS (8) (not supplied).
NOTE: White wire to white wire & black wire to black wire.
3. Feed LOW VOLTAGE RELAY WIRES (5) through opening in the LVT COVER PLATE (6) and connect to the two contact screws of INLET VALVE FACE PLATE (9).
4. Push Inlet Valve face plate (10) into MOUNTING PLATE (11). At the same time, push ELECTRICAL CONDUCTORS (12) and connectors (8) into WIRING COMPARTMENT (4). Back out the two screws that hold the wiring compartment in place. Slip upper FINISHED WALL CLIP (13) under the screw heads and tightly fasten both wiring compartment and upper finished-wall clip (13) with MOUNTING SCREWS (supplied).
5. Install the lower FINISHED WALL CLIP (14) with screws (supplied).
6. Secure Inlet Valve face plate (10) to mounting plate (11) using the two supplied colour matched SCREWS (15).

FINISHED CONSTRUCTION

After pipe, low voltage relay control wire, electrical building wires and opening in wall has been cut:

1. Remove mounting plate NAILING FLANGE (16). Use a hack saw or score with razor knife along dotted line and snap off.
2. Repeat step one (from NEW CONSTRUCTION).
3. Install modified mounting plate with short 90° ELL glued in position into wall opening.
4. Repeat steps 2-6 (from NEW CONSTRUCTION).



WARNING!
TO REDUCE RISK OF FIRE AND ELECTRIC SHOCK
USE ONLY WITH HAYDEN SUPERHOSE AND
SUPERHOSE II. DO NOT OPERATE HOSES ON WET
SURFACES!